


iPhone Camera Modes

Compiled by Bob Spalding



The camera modes are built into your iPhone to help you take the ideal photo or video.

The camera modes are listed at the bottom of the Camera App. The various modes can be reached by swiping from left or right. The newer iPhones have 6 camera modes: Time Lapse, Slo-Mo, Video, Photo, Portrait and Pano.

Time-Lapse Mode: will allow the user to create a sped-up video footage of something in motion over a period of time.

Slo-Mo Mode: will record a video with a slow motion effect.

Video Mode: will allow the user to record videos.

Photo Mode: will allow you to take a basic still photo of a subject.

Portrait Mode: will allow you to blur the background as well as take basic portraits of people and/or pets.

Pano Mode: allows the user to photograph a super wide area. The iPhone will automatically stitch them together to give the user a wide photograph